

Running The Sterilizer

Starting the sterilizer (takes 10-20 minutes)

1. Open the sterilizer door. If it has water in the bottom, remove the plastic core...



2. ... and press the DRAIN button several times until water is gone.



Then replace plastic core in bottom of sterilizer and close its door.

3. Run water in the sink until it is hot. Turn the lever to the right for hot.



4. Turn on the sterilizer by pressing the POWER button.



When the TEMP GUARD light comes on ...



... the sterilizer is ready to go. It takes some time to heat up.

Steps for using the sterilizer

1. **Important** In the sink, soak or wash mugs, plates, etc. as necessary, to remove any food, chocolate residue, etc.

The sterilizer does not scrub the dishes; it just sterilizes them.

2. Choose a rack or racks from the cabinet in front of the island:



3. Load the rack with nearly clean dishes. You can also use the special basket for silverware or utensils.



4. Place the loaded rack in the sterilizer, close the door, and press the CYCLE button.



- If it does not start immediately, the machine may be still heating up the water.
- Cycles run for 2-3 minutes.

5. When the CYCLE light goes out, remove rack—it's hot, so be careful.
6. Let the dishes air dry or dry them with a dish towel and put them away.
7. Repeat the soaking, loading, and sterilizing, and drying steps until everything is clean.
8. Turn off the sterilizer by pressing the POWER button.



9. Remove the plastic core.



10. Press the DRAIN button repeatedly until all the water is pumped out. It makes a different sound when there is no more water in the pump.



11. Replace the plastic core.



Note Any dishes that come in late can be loaded into the (regular) dishwasher. Start it just before you leave.